INTERNATIONAL MARITIME ORGANIZATION

4 ALBERT EMBANKMENT LONDON SE1 7SR

Telephone: 0171-735 7611 Fax: 0171-587 3210 Telex: 23588 IMOLDN G

Ref. T1/3.02



E

MSC/Circ.920 15 June 1999

MODEL LOADING AND STABILITY MANUAL

- The Maritime Safety Committee, at its seventy-first session (19 to 28 May 1999), noting the need for Administrations and industry to be provided with guidance on the preparation of loading and stability manuals, using a uniform layout as well as agreed terms, abbreviations and symbols for the correct use of such manuals by mariners, approved the Model Loading and Stability Manual set out in the annex.
- 2 Member Governments are invited to use the annexed Model and bring it to the attention of all parties concerned.

ANNEX

MODEL LOADING AND STABILITY MANUAL

Table of contents

Section 1 -	Identification	and approval
-------------	----------------	--------------

Section 2 - Guidance to the master

- 2.1 Introduction
- 2.2 Terms, symbols and units
- 2.3 Explanations to the manual
- 2.4 Operation of the ship
- 2.5 Typical approved loading conditions
- 2.6 Control of stability, trim and longitudinal strength

Section 3 - Technical information (Category 1 and 2)*

- 3.1 Capacity plan
- 3.2 Cargo space information
- 3.3 Tank space information
- 3.4 Hydrostatic particulars
- 3.5 Lightship particulars
- 3.6 Load line particulars
- 3.7 Stability limits
- 3.8 Longitudinal strength criteria
- 3.9 Other operational restrictions

Section 4 - **Reference information (Category 3)***

- 4.1 Inclining experiment report
- 4.2 Intact stability criteria
- 4.3 Other information

^{*}Information categories are defined as follows:

^{.1} category 1A information is information which includes all basic data necessary to obtain the trim and stability characteristics of the ship;

^{.2} category 1B information is optional information which is deemed, by owners, to be necessary and useful material appropriate to the operation of the ship;

^{.3} category 2 information is information which provides the master with ready means of ensuring that the ship's stability parameters for the given service and condition of loading lie within the limits required by the Administration; and

^{.4} category 3 information is supportive information, not necessary for the use on board, which may be required by Administrations for the verification of the information under categories 1 and 2.

Section 1 - Identification and approval

- 1.1 This section should contain information deemed suitable by the Administration to clearly identify the ship with regard to the applicability and approval of this manual.
- 1.2 The information in this section should include:
 - .1 ship's name and type/purpose of ship;
 - .2 name of builder and yard number;
 - .3 date of build/conversion (keel laying or delivery);
 - .4 particulars of classification;
 - .5 nationality, port of registry and official number;
 - .6 principal dimensions;
 - .7 other information, if deemed necessary; and
 - .8 IMO Number.
- 1.3 The pages of the manual should be numbered beginning with section 1. The total number of pages should be stated in this section.
- 1.4 The approval of the manual by, or on behalf of, the Administration should be stated in this section together with the prominent indication of any restrictions regarding the area or season of operation or any other relevant issues. This approval should, in addition, be certified on the front cover of the certificate.

Section 2 - Guidance to the master

2.1 Introduction

- 2.1.1 The introduction should address the general purpose of the manual, i.e.:
 - .1 to provide all necessary information to the master for the proper loading and ballasting of the ship and for the control of stability, draught and structural integrity, if needed;
 - .2 to satisfy the requirements of the flag State Administration with regard to approval according to regulation II-1/22 of the International Convention for the Safety of Life at Sea, 1974, as amended, regulation 10 of the International Convention on Load Lines, 1966 and regulation III/10 of the 1993 Torremolinos Protocol; and
 - .3 to stress the need for the masters to exercise prudence and good seamanship, having regard to the season of the year, weather forecasts and the navigational zone, and to take the appropriate action as to speed and course warranted by the prevailing conditions.

2.1.2 A statement should, if applicable, identify the optional information contained in the manual, which may be deemed by owners to be useful material appropriate to the operation of the ship, and the accuracy and correctness of which falls under the responsibility of the owners. This type of information is referred to as category 1B information.

2.2 Terms, symbols and units

- 2.2.1 It is of utmost importance for the practical use of the manual by the mariner that terms, symbols and units comply with relevant ISO standards.* A statement of this compliance should be given in this section.
- 2.2.2 The terms, symbols and units considered necessary in a typical loading and stability manual are shown in table 1. Sketches, such as shown in figures 1, 2 and 3, depicting the above symbols, should be included in the manual as deemed appropriate.

^{*}ISO 7462 and ISO 7463, as revised by 2000.

Table 1: Terms, symbols and units

unit
-
-
-
-
; (°)
n
n
n
n
n
n
n
n
n
n
n
n
n
n
1^3
(t)
(t/cm)
(UCIII)
n
n
n
n
n
n
n
n
n
n
n
n
1 ⁴
(tm/cm)
(tm/em)
, ,
,
m^2
(kn)
n n
n n
(t/m^3)




Figure 1




Figure 2




Figure 3

2.3 Explanations to the manual

- 2.3.1 This subsection should contain explanations to this manual, in particular to technical information in section 3, if deemed necessary. This should include but not be limited to:
 - .1 reference planes and signs of trim;
 - .2 applicability of hydrostatic data with regard to trim;
 - .3 applicability of stability limits with regard to trim, height of deck cargo or other parameters; and
 - .4 general advice on the use of tables or diagrams with regard to accuracy and interpolation.
- 2.3.2 Explanations given in this subsection should be repeated at the specific technical information, table or relevant issue in a suitable manner.

2.4 Operation of the ship

- 2.4.1 This sub-section should characterize the lightship with regard to stability, trim, heeling-moment due to asymmetrical equipment and longitudinal stress parameters.
- 2.4.2 If applicable, the preferred compensation of asymmetrical light ship mass by ballast, consumables or cargo should be explained. A warning against compensation by solid bulk cargo should be given.
- 2.4.3 The concept of the distribution of consumables in different stages of consumption, such as full, partly filled and minimal arrival conditions, should be explained including the effect on KG in loaded condition.
- 2.4.4 The concept of the compensation of increase of KG due to fuel consumption during the voyage by taking ballast should be explained. A suitable table or diagram should be used, where appropriate.
- 2.4.5 The general stress situation in terms of bending moments and shear forces should be commented for typical and, if necessary, for unusual loading conditions. Warnings should be given against extreme stress situations which may arrive with specific distributions of cargo and/or ballast, e.g. filling the forepeak or afterpeak. Similar warnings should be given against undue torsional moments, if appropriate.
- 2.4.6 The principal ballast patterns should be explained for the carriage of heavy deck cargo, like containers, or light cargo in the hold, like ro/ro-vehicles.
- 2.4.7 Specific information should be given regarding the effect of hoisted crane booms, filled swimming pool or other heavy top masses on the ship's stability, and the correct use of anti-rolling devices and/or heeling tanks, if applicable.
- 2.4.8 All relevant operating limits with regard to loading and distribution of cargo and ballasting should be listed and explained, as for example:
 - .1 maximum draught according to Load Line Certificate;

- .2 maximum KG_c-values according to intact stability criteria or damage stability criteria;
- .3 maximum allowable shear forces and bending moments;
- .4 restrictions to deck stowage and trim due to SOLAS-sight lines;
- .5 minimum draught foreward and aft with regard to seakeeping;
- .6 maximum draught foreward due to minimum bow height requirement;
- .7 maximum stack loads for container stacks;
- .8 maximum load per area for break bulk cargoes; and
- .9 maximum load per hold for bulk cargoes.

Reference should be made to the Damage Control Manual and the Cargo Securing Manual, if applicable.

- 2.4.9 A general warning should be given that tanks which are not in use should, where practical, be either completely empty or completely filled up, in particular where the stability is marginal.
- 2.4.10 A general warning should be given of the reduction of stability by a steady angle of heel of the ship. It is essential to keep the ship upright at all times by a symmetrical distribution of masses.

2.5 Typical approved loading conditions

- 2.5.1 As a minimum, the following loading conditions should be compiled and calculated for any ship in accordance with MSC/Circ.456:
 - .1 lightship condition;
 - .2 docking condition;
 - .3 loading conditions as stipulated in 3.5.1, 4.2.5 and 4.5.7 of the Intact Stability Code (resolution A.749(18)), as amended; and
 - .4 table of summary of loading conditions.
- 2.5.2 Assumptions for calculating loading conditions should be in accordance with 3.5.2, 4.1.8 and 4.5.8 of the Intact Stability Code, as amended. Where icing is likely to occur the loading conditions should take this into account.
- 2.5.3 As calculated loading conditions will be used by the master to obtain a realistic picture of the cargo carrying capabilities of the ship, it is recommended to include a limited number of fully loaded conditions with approximately half capacity of consumables on departure. The consequential surplus of cargo carrying capacity may be partly used for low ballast if the excess cargo is to be loaded on deck. The subsequent arrival condition with 10% consumables should be provided as well.

- 2.5.4 If, due to the nature of the cargo and its typical stowage pattern, stability may become the limiting parameter for the loading concept in general (e.g., containerships, ro-ro ships, ships carrying timber on deck), the calculated loading conditions should present "limit conditions" with regard to load line and stability requirements either for departure or arrival or both.
- 2.5.5 Each presented condition of loading should include:
 - .1 A sketch of the ship indicating pictorially the main items of deadweight included in the displacement, side view and top view if useful.
 - .2 A table showing lightship mass and all components of the deadweight together with the positions of their centres relative to the defined reference planes.
 - The summation should show the displacement and the positions of its centre. Positions should be shown along the vertical and longitudinal axes. For containerships and ro-ro ships, the inclusion of the transverse co-ordinate is recommended. The free surface moments of slack tanks for zero degree heel should be included in this table in accordance with 3.3 of the Intact Stability Code, as amended.
 - .3 A diagram showing the curve of righting levers plotted against the angle of inclination. The righting levers are to be corrected for free surface effects in accordance with 3.3 of the Intact Stability Code, as amended. Wind and/or other heeling lever curves should be superimposed on the diagram as appropriate. The scales used in this diagram should be the same for each loading condition in the manual.
 - .4 A summary of the appropriate condition should contain as a minimum:
 - .1 displacement;
 - .2 corresponding draught (i.e. draught at centre of flotation);
 - .3 moment to change trim one unit (metre or centimetre);
 - .4 longitudinal position of centre of buoyancy;
 - .5 longitudinal position of centre of mass;
 - .6 longitudinal position of centre of flotation;
 - .7 trim over perpendiculars;
 - .8 draught at forward perpendicular;
 - .9 draught at after perpendicular;
 - .10 draught at mid between perpendiculars;
 - .11 total free surface moment for initial stability;

- .12 vertical position of the transverse metacentre (for trimmed condition if trim exceeds 1% of the length of the ship);
- .13 vertical position of the ship's centre of mass, uncorrected and corrected for free surface effects;
- .14 transverse metacentric height uncorrected and corrected for free surface effects; and
- a statement giving the limiting value or values of stability parameters taken from data under 3.6 and the comparison with corresponding values achieved.
- .5 Draught and other hydrostatic data to be obtained from immersed gross volume in sea water ($D = 1.025 \text{ t/m}^3$). If the ship is intended to operate in areas of less water density the appropriate immersed gross volume may be used if agreed by the flag State Administration.
- .6 Draught statements should refer to bottom of keel. This should be clearly indicated.
- 2.5.6 Each calculated loading condition should be commented or explained highlighting the specific features of the particular condition with regard to:
 - .1 operating limits (see 2.4.8);
 - .2 ballast operations between departure and arrival due to fuel consumption, water soaking of deck cargo or other reasons;
 - .3 limitations to stowage factor of cargo or to average container masses per tier;
 - .4 restrictions to the positioning of ship's equipment and other heavy masses or usage of swimming pool;
 - .5 amount and distribution of consumables;
 - .6 minimum filling of slack ballast tanks to avoid excessive sloshing (in the case of high initial stability); and
 - .7 any other important aspects.

2.6 Control of stability, trim and longitudinal strength

- 2.6.1 Reference to the ship's approved loading and stability computer should be made and to the user guide provided with this computer, if applicable.
- 2.6.2 A simple guidance should be given for the manual calculation of stability, draught and trim, which may be required for the control of loading conditions outside the scope of conditions under 2.5 on ships not equipped with an approved loading and stability computer, or if such computer fails. The use of suitable form sheets is recommended for this purpose.

	2.6.3	This sub	section	should,	if ap	propriate,	present t	the fol	llowii	ng form	sheets	foi
--	-------	----------	---------	---------	-------	------------	-----------	---------	--------	---------	--------	-----

- .1 compiling mass and position of consumables and stores;
- .2 compiling mass and position of ballast;
- .3 compiling mass and position of cargo;
- .4 compiling mass and position of fishing gear;
- .5 compiling mass and position of ice accretion;
- .6 compiling displacement and position of centre of displacement and evaluating draught and trim; and
- .7 plotting a righting lever curve and, where appropriate, a wind heeling lever curve.
- 2.6.4 The form sheet under 2.6.3.3 should suit the particular type or types of cargo the ship is intended to carry, i.e. a different layout may be required for:
 - .1 break bulk;
 - .2 containers:
 - .3 ro/ro-vehicles;
 - .4 bulk cargoes (solid or liquid);
 - .5 fish; and
 - .6 ice.

For cargoes with a structured stowage pattern like containers or ro/ro-vehicles, separate form sheets for calculating the vertical and the longitudinal position of the centre of cargo mass may be useful.

2.6.5 A model of the form sheets under 2.6.3.4 and 2.6.3.5 is shown in the tables 2 and 3 below.

Line		Manual calculation of stability and trim								
0	ItemMass tXG mLong. mom. t @mZG mVert. mom. t @m									
1	Light ship	4055.4	47.55	192835.2	9.75	39540.3	-			
2	Consumables									
3	Ballast									
4	Cargo									
5	Miscellaneous									
6	Displacement									
7	XG of displaceme	XG of displacement = E Long. mom./Displacement = <u>m</u>								
8	With displacement for ship in seawate		m the hydro	ostatic table referre	d to in 3.4	4.2				
9	$T_{KC} = \underline{m};$	MTM =	t@	<u>n/m;</u> XB =	<u>m</u> ;	XF =	<u>m</u>			
10	Trim =	Displac	ement · (XC	<u>G - XB)</u>		=	<u>m</u>			
11	Draught at AP:	$T_{KA} =$	T_{KC} - t	$@XF/L_{pp}$		=	<u>m</u>			
12	Draught at FP:	$T_{KF} =$	T _{KC} - t	$@(XF - L_{pp})/L_{pp}$		=	<u>m</u>			
13	KG of displaceme	ent = E Vert	. mom./Disj	placement		=	<u>m</u>			
14	$KG_c = KG + E (i_F)$	@D)/Displa	cement			=	<u>m</u>			
15		l the maxim	um permiss	n deck, obtain fron ible KG_c , which show.			<u>m</u> .			

Note: Calculation in lines 10 to 12 should follow algebraic rules regarding signs. Negative sign is attributed to trim by stern.

Table 2: Form for evaluating displacement, draughts and stability

Line	N	0	10	20	30	40	50	60	70	80
1	LK	m								
2	KG _c @s	in N m								
3	GZ	m								
4	KM =		<u>m</u> ;	KG _c =	<u> </u>	<u>m</u> ;	$GM_c =$	KM - K	$G_c = \underline{\hspace{1cm}}$	m
			_							
	.6							#		
GZ	.5							#		
(m)	.4							#		
	.3							#		
	.2							#		
	.1							#		
	0	0	10	20	30	40	50	# 60 57.3	70	N (°)

Table 3: Form for calculating and plotting the righting lever curve (the GZ-axis may be expanded if necessary)

- 2.6.6 One calculated example should be provided together with explanatory comments. A note should be given that in calculating a loading condition, at least one (or pair of) fuel and fresh water tank should be considered slack.
- 2.6.7 If the ship is equipped with an approved installation for performing in-service inclining tests, a reference note should be given to the operations manual of this equipment, or, if deemed appropriate, comprehensive guidance placed in this subsection.

If, on request by the owner, the loading and stability manual is to contain additional technical information for supporting a draught survey or other stability management issues, appropriate guidance and calculated examples should be given in this subsection. The Guidelines on the management of ship's stability, to be developed by the Organization, should be taken into account, if appropriate.

Section 3 - Technical information (Category 1 and 2)

3.1 Capacity plan

3.1.1 This subsection should contain a scaled drawing showing the layout of cargo spaces, tanks, stores, machinery spaces and crew/passenger accommodation. Cargo spaces and tanks should be suitably identified by purpose, names and/or numbers consistent with other information in this manual.

- 3.1.2 The above plan should, in addition, present:
 - .1 reference planes and the rise of keel, where applicable;
 - .2 frames, frame spacing and numbering; and
 - .3 location of draught marks forward, mid and aft.
- 3.1.3 The reference planes should preferably be at the:
 - .1 aft perpendicular for the longitudinal coordinates;
 - .2 centre line for the transverse coordinates; and
 - .3 base line for the vertical coordinates.
- 3.1.4 The above plan should, in addition, present a diagram of the load line marks showing:
 - .1 position of the deck line relative to the ship;
 - .2 draught to the summer load waterline;
 - .3 draught to the summer timber load waterline;
 - .4 corresponding freeboards; and
 - .5 deadweight scale.

3.2 Cargo space information

- 3.2.1 This subsection should present information on cargo spaces in the form of a suitable table containing:
 - .1 name and/or number of space;
 - .2 frame numbers at forward and aft end of space;
 - .3 volume at 100% filling; and
 - .4 longitudinal, transverse and vertical co-ordinates of the centre of volume with regard to the reference planes.
- 3.2.2 On break-bulk ships, additionally, the permissible surface load per area for the particular deck or tanktop should be given in t/m^2 . The volume of spaces may be given separately for bale cargo and for grain, if appropriate.
- 3.2.3 On bulk carriers, the permissible total mass of cargo in the particular space should be given.

- 3.2.4 On tankers, additionally, the volume at 98% filling and the moment of inertia of the free surface at 98% filling should be given.
- 3.2.5 On ships equipped for the carriage of containers, a detailed container stowage plan should be provided using an accepted numbering system and presenting the longitudinal, transverse and vertical co-ordinates of the assumed centres of mass of containers. The vertical co-ordinates should refer to a centre of mass at 50% of container height of ISO containers of 8'06" height. If the ship is intended to carry other types of containers, their appropriate height should be used.

Any reduction of vertical co-ordinates with regard to the assumption of centre of mass should be indicated. Maximum stack masses and maximum stack heights of containers may be included in this information.

3.2.6 On ro-ro ships, the stowage lanes should be suitably subdivided for identifying longitudinal co-ordinates of stowage positions. The vertical co-ordinates should refer to 2 m above the deck level, unless the cargo in a specific trade requires a different value.

3.3 Tank space information

- 3.3.1 This subsection should present information on tank spaces intended for fuel, stores, feed water, domestic water, process liquids and liquid waste in the form of suitable tables showing:
 - .1 name and/or number of tank and designated contents;
 - .2 frame numbers at forward and aft end of tank;
 - .3 volume at 100% filling;
 - .4 density of the liquid (D);
 - .5 mass at 100% filling;
 - .6 longitudinal, transverse and vertical co-ordinate of centre of volume; and
 - .7 maximum value of moment of free surface $(i_B @D)$.
- 3.3.2 Separate summary tables may be included for:
 - .1 full consumables with waste reception tanks empty and full free surfaces for one (or pair of) fuel and fresh water tank;
 - .2 approximately half capacity of consumables and waste reception tanks;
 - .3 minimal arrival capacity of consumables with waste reception tanks full; and
 - .4 typical ballast configurations required for substantial deck cargoes or ships with sensible stability.

The results of these summary tables should be used in the appropriate loading conditions in this manual.

- 3.3.3 For deep tanks, side tanks, peak tanks and other tanks with unusual shape, holding more than 0.1% of the ship's summer displacement, individual sounding tables should be provided presenting tank identification, contents, density and:
 - .1 sounding in steps of 0.1 m or less;
 - .2 contents volume at given sounding;
 - .3 longitudinal, transverse and vertical co-ordinate of centre of contents; and
 - .4 moment of free surface $(i_B @D)$.
- 3.3.4 For deep tanks, including cargo tanks, with a width of 0.6 @B or more, separate individual tables should be provided presenting tank identification, contents, density and:
 - .1 sounding in steps of 0.1 m or less;
 - .2 contents volume at given sounding; and
 - .3 volumetric heeling moment of given volume at heeling angles from 10° to 80° at intervals of 10° .

The heeling moments of liquid volumes should be computed in accordance with 3.3 of the Intact Stability Code, as amended.

3.4 Hydrostatic particulars

3.4.1 Hydrostatic particulars should be presented for the ship on even keel or design trim without deflection in a table against draught to the bottom of keel over a range from light ship to 115% of the maximum draught or to the depth of hull, whichever is less.

The tabulated intervals should be not greater than 5 cm. Values should be rounded to decimal places shown below.

3.4.2 The tabulated values should include:

T _{KC} m	DISV m ³	DISM t	TPC t/cm	KM m	MTM tm/m	XB m	XF m
6.05	8677,3	8894.3	18.00	9.038	10783	59.48	58.78

Instead of MTM, the values of MTC may be used (see subsection 2.2). The position of reference planes should be confirmed for KM, XB and XF.

3.4.3 Where the operation of the ship results in loading conditions having significant trim, i.e. trim exceeding 0.01 @L, additional hydrostatic particulars should be prepared for a suitable range of trim.

This applies in particular to the z - co-ordinate of the metacentre KM which should be given for ships where stability may become critical due to cargo stowage pattern. The following presentations should be used, if appropriate:

T _{KC}	KM for trimmed conditions (m)								
m	t = -3 m	t = -2 m	t = -1 m	t = 0 m	t = 1 m	t = 2 m			
	٠	•			•				
8.20 m	9.523	9.422	9.332	9.256	9.217	9.162			
	٠	•	•	•	•	•			

3.4.4 Cross curve data should be provided for the same conditions as lined out under 3.4.1 for heeling angles from 10° to 80° at 10° intervals. Closer spacing or particular angles may be required for certain ships or special purposes, e.g. grain stability.

Where the operating trim or the form and arrangement of the ship are such that change in trim has an appreciable effect on righting arms, additional cross curve tables should be included for a suitable range of trim. A statement should be appended to the table indicating the erections and/or timber deck loads which are included in the cross curve values.

T _{KC} m	LK 10° m	LK 20° m	LK 30° m	LK 40° m	LK 50° m	LK 60° m	LK 70° m	LK 80° m
6.60	1.578	3.207	4.773	6.067	7.030	7.560	7.748	7.650
•	•	•	•	•	•	•	•	•
٠	٠	•	٠	٠	٠	•	٠	•

3.5 Lightship particulars

- 3.5.1 This subsection should present data resulting from the inclining experiment and deadweight survey:
 - .1 lightship mass;
 - .2 longitudinal, transverse and vertical centre of mass including the relevant reference planes;
 - .3 calculated and measured deflection of the hull, if appropriate;
 - .4 place and date of the inclining experiment; and
 - .5 name of organization responsible for the approval of the above results.

- 3.5.2 If dispensation from carrying out an inclining experiment has been given, the name of the authority and the reasons should be stated including details of the reference ship or ships from where the data have been concluded.
- 3.5.3 If permanent ballast is contained in the light ship mass, a description of such ballast should be included giving the material, its mass and distribution to the common reference planes. A sketch showing the distribution of such ballast should be included.
- 3.5.4 If a rolling period test is required by the Administration details of the result should be given.

3.6 Load line particulars

- 3.6.1 This subsection should contain a statement giving the type of load line assigned (i.e. type A, B, etc.) and a table showing for the appropriate load line marks (winter, summer, tropical, etc.) the values of:
 - .1 draught to bottom of keel;
 - .2 freeboard;
 - .3 displacement mass in seawater ($D = 1.025 \text{ t/m}^3$); and
 - .4 deadweight.
- 3.6.2 If the assessment of freeboard is based on a design trim other than zero, this should be stated. Furthermore, the maximum permissible draught at the forward perpendicular if necessary for bow height consideration should be stated.
- 3.6.3 Minimum draught forward and minimum draught aft should be stated with regard to ship handling in heavy weather. This information may be regarded as category 1B information.

3.7 Stability limits

3.7.1 This subsection should contain a precalculated table from which the master can determine whether the stability of the ship is acceptable for a given loading condition under the governing stability criteria. This information should preferably show the maximum allowable height of the loaded ship's centre of gravity KG_c , i.e. appropriately corrected for free surfaces, against the reference keel draught T_{KC} .

If the maximum allowable KG_c depends on specific parameters, e.g. height of deck cargo, layers of containers on deck, trim, or other conditions of service, the table or tables should provide for any suitable combination of limiting KG_c values. If, in particular the trim is considered not to influence the limiting KG_c values, this should be clearly stated.

The range of data should extend from the lightest anticipated seagoing draught to the minimum freeboard assigned. An example for such table is given below:

T_{KC}	Max	Maximum permissible KG _c for any operating trim (m)									
m	no containers on deck	1 tier deck containers	2 tier deck containers	3 tier deck containers	4 tier deck containers						
•		•	·	·							
5.20	9.05	9.05	9.05	8.99	8.85						
•											

- 3.7.2 The alternative presentation of minimum values of metacentric height, corrected for free surfaces, as a determining parameter of compliance with stability criteria should not be used for ships where stability management is likely to incorporate the in-service inclining test. The presentation, however, of maximum KG_c values as limiting parameters will prompt the user to obtain the actual KG_c from the measured GM_c . In the case of notable trim, the user should utilize KM for trimmed condition.
- 3.7.3 The angle of down flooding, as defined in paragraph 3.2.2.1.5 of the Intact Stability Code, should be tabulated against the reference keel draught T_{KC} for the ship on even keel or design trim over the range defined under 3.7.1. The critical openings should be identified together with their co-ordinates to the common reference planes.
- 3.7.4 A separate set of information should, in the form of suitable tables and/or diagrams, provide the appropriate damage stability criteria. The form of presentation should be similar to the presentation of the intact stability criteria as far as practicable.

3.8 Longitudinal strength criteria

- 3.8.1 This subsection should contain, in a suitable table for selected longitudinal positions, i.e. frames or bulkheads the:
 - .1 frame number and longitudinal co-ordinate;
 - .2 maximum permissible shearforces, positive and negative, for operation in port and at sea; and
 - .3 maximum permissible bending moments, positive and negative, for operation in port and at sea.

		Shea	r force limi	t (kN)	Bending	moment lim	nit (kNm)
Frame	x - co-ordinate	at sea		in port	at sea		in port
•	•			•	•	•	•
64	44,2 m	21050	- 20750	± 25350	292850	- 240400	± 465350
	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•

If those limiting values depend on specific parameters, e.g., homogeneous or alternating cargo distribution, draught, or other conditions of service, additional tables should be provided as appropriate.

- 3.8.2 A separate table for pre-estimating the ship's deflection from bending moments in the full sections of the ship may be provided in this subsection. This information should reflect any constant deflection as may be identified during the initial inclining experiment and deadweight survey, if required. The maximum allowable deflection (hog or sag) in port and at sea should be specified. The information addressed to in this paragraph may be considered as category 1B information.
- 3.8.3 Maximum allowable torsional moments should be provided in a table as described under 3.8.1 for ships which are sensible to torsion due to their construction and cargo stowage practice.

3.9 Other operational restrictions

- 3.9.1 This subsection should contain information and/or reference to other operational restrictions related to the loading and the operation of the ship. This may include:
 - .1 trim and/or deck-stowage restrictions due to SOLAS-sightlines;
 - .2 restrictions to high initial stability with regard to securing of deck cargoes, in particular containers (refer to the Cargo Securing Manual);
 - .3 stability and trim requirements with regard to damage control (refer to the Guidelines for damage control plans, MSC/Circ.919);
 - .4 operating restrictions with regard to ship handling in heavy weather (refer to the Guidance to the master for avoiding dangerous situations in following and quartering seas (MSC/Circ.707)); and
 - .5 maximum permissible draught (scantling draught) corresponding to structural strength of the ship.
- 3.9.2 The information in this subsection may be transferred to subsection 2.4 (Operation of the ship), if deemed useful.

Section 4 - Reference information (Category 3)

This section should contain information which is not necessary for the operation of the ship but deemed useful as reference for the master and/or necessary for the approval by the Administration.

4.1 Inclining experiment report

The inclining test report presented in this subsection should be detailed to the satisfaction of the Administration.

4.2 Intact stability criteria

This subsection should contain the relevant text of the intact stability criteria assigned to the ship by the flag State Administration and which are the basis for stability limits presented in subsection 3.7.

4.3 Other information

This subsection should contain other reference information deemed useful by the Administration or owners.